






MINTO 403-194YW  
 ASSEMBLY INSTRUCTIONS  
 INSTRUCTION D'ASSEMBLAGE



Ax1



Bx1



Cx1



Dx4




Ex1




Fx5





Gx1





1



2



3



4